
STRAIGHT GRAIN
5520 Dress
BACK_GUSSET
Fabric type TOP_FABRIC, Piece qty =(1,0)
X
DO NOT USE

STRAIGHT GRAIN
5520 Dress
FRONT_GUSSET
Fabric type TOP_FABRIC, Piece qty =(1,0)
X
DO NOT USE


STRAIGHT GRAIN
5520 Dress
FRONT_PANEL
Fabric type TOP_FABRIC, Piece qty =(1,1)
X
USE ONE
STRAIGHT GRAIN
5520 Dress
BACK_PANEL
Fabric type TOP_FABRIC, Piece qty =(1,1)
X
USE ONE


STRAIGHT GRAIN
5520 Dress
DENIM_UPPER_BACK_PART
Fabric type TOP_FABRIC, Piece qty =(1,0)
STRAIGHT GRAIN
5520 Dress
DENIM_UPPER_FRONT_PART
Fabric type TOP_FABRIC, Piece qty =(1,0)
STRAIGHT GRAIN
5520 Dress
SIDE_UPPER_FRONT_PART
Fabric type TOP_FABRIC, Piece qty =(1,0)
STRAIGHT GRAIN
5520_Dress
SNAPED_BELT_FRONT
Fabric type TOP_FABRIC, Piece qty =(1,0)
X
STRAIGHT GRAIN
5520 Dress
SNAPED_BELT_BACK
Fabric type TOP_FABRIC, Piece qty =(1,1)
X
USE ONE
STRAIGHT GRAIN
5520 Dress
ARES_SIDE_PART_BACK
Fabric type TOP_FABRIC, Piece qty =(1,0)